

User guide: RC2 Tripod Stillage



This guide illustrates how to use the RC2 Tripod Stillage. The rugged RC2 Tripod Stillage is designed for both storage and transit purposes. The transport case features strap locators to allow secure tie-down to the vehicle flatbed and can be stacked for convenient storage. When used, the stillage protects the vital components of the signal such as radar and antenna from damage.

SAFETY GUIDANCE

- Stillage with Signal weighs approx. 40kg.
- 2 man required
- Sack truck recommended



Lay stillage flat on a level surface.



Place the Tripod in the stillage. Wrap the webbing strap around the tripod and through the side handle.



Loop the webbing strap underneath the stillage and through the opposite handle.



Carefully place the signal head face up in the stillage, bottom first to protect the radar and antenna.



Loop the webbing strap through the cam buckle and tighten, taking care not to over-tighten or scratch signal aspects.



With the signal secure, move using a lightweight sack truck or carry the stillage flat with a second person.

Need assistance? Please call 0345 460 9999